

Samsung Remote Codes from ESP8266 IRRecDumpV3

Remote Model #: BN59-01301A

	hex	decimal
power	0xE0E040BF	3772793023
source	0xE0E0807F	3772809343
	1 0xE0E020DF	3772784863
	2 0xE0E0A05F	3772817503
	3 0xE0E0609F	3772801183
	4 0xE0E010EF	3772780783
	5 0xE0E0906F	3772813423
	6 0xE0E050AF	3772797103
	7 0xE0E030CF	3772788943
	8 0xE0E0B04F	3772821583
	9 0xE0E0708F	3772805263
	0 0xE0E08877	3772811383
-	0xE0E0C43B	3772826683
pre-ch	0xE0E0C837	3772827703
vol+	0xE0E0E01F	3772833823
vol-	0xE0E0D02F	3772829743
mute	0xE0E0F00F	3772837903
ch list	0xE0E0D629	3772831273
ch up	0xE0E048B7	3772795063
ch dwn	0xE0E008F7	3772778743
sleep	0xE0E0C03F	3772825663
home	0xE0E09E61	3772816993
guide	0xE0E0F20D	3772838413
settings	0xE0E058A7	3772799143
up arrow	0xE0E006F9	3772778233
left arrow	0xE0E0A659	3772819033
right arrow	0xE0E046B9	3772794553
down arrow	0xE0E08679	3772810873
info	0xE0E0F807	3772839943
center arrow	0xE0E016E9	3772782313
return	0xE0E01AE5	3772783333
exit	0xE0E0B44B	3772822603
rewind	0xE0E0A25D	3772818013
play	0xE0E0E21D	3772834333
pause	0xE0E052AD	3772797613
ffw	0xE0E012ED	3772781293
stop	0xE0E0629D	3772801693
e.manual	0xE0E0FC03	3772840963
p.size	0xE0E07C83	3772808323
cc/vd	0xE0E0A45B	3772818523
a	0xE0E036C9	3772790473
b	0xE0E028D7	3772786903
c	0xE0E0A857	3772819543
d	0xE0E06897	3772803223