



RORAIMA 2000/3000/40000/5000

- | | | |
|-----------------------|------------------------------|--------------------|
| 1 DRAG KNOB ASSY. | 25 SCREW | 49 O/S GEAR |
| 2 SPOOL SNAP RING | 26 SCREW | 50 SCREW |
| 3 KEY WASHER | 27 BAIL HOLDER SLIDER | 51 O/S SLIDER |
| 4 BRAKE WASHER | 28 SPRING LEADER | 52 SCREW |
| 5 EARED WASHER | 29 SPRING | 53 SLIDER SQUASH |
| 6 BALL BEARING | 30 BAIL ARM COVER | 54 SCREW |
| 7 BALL BEARING | 31 SCREW | 55 BALL BEARING |
| 8 SPOOL ASSY. | 32 SCREW | 56 DRIVE GEAR |
| 9 CLICK GEAR WASHER | 33 LOCATING DEVICE COVER | 57 GEAR WASHER |
| 10 CLICK GEAR PIECE | 34 BALL BEARING | 58 BALL BEARING |
| 11 MAIN SHAFT | 35 LOCATING DEVICE | 59 MAIN BODY COVER |
| 12 SCREW | 36 ONE WAY | 60 SCREW |
| 13 BALANCE | 37 ANTI-REVERSE PAWL SPRING | 61 MAIN BODY INLAY |
| 14 HEXAGON NUT | 38 PINION GEAR | 62 HEXAGON SHAFT |
| 15 BAIL HOLDER | 39 ANTI-REVERSE SHAFT | 63 HANDLE CANNULA |
| 16 SCREW | 40 ANTI-REVERSE KNOB | 64 BOLT BAR |
| 17 ROTOR SHELL | 41 ANTI-REVERSE SPRING LEVER | 65 HANDLE |
| 18 SCREW | 42 SCREW | 66 GRIP CANNULA |
| 19 BAIL SPRING ASSY. | 43 HANDLE CAP/SCREW | 67 GRIP |
| 20 LINE ROLLER | 44 PAPER WASHER | 68 GRIP CANNULA |
| 21 BALL BEARING | 45 MAIN BODY INLAY | 69 GRIP RIVET |
| 22 BALL BEARING | 46 MAIN BODY | 70 GRIP CAP |
| 23 LINE ROLLER WASHER | 47 REAR COVER | |
| 24 BAIL ARM | 48 SCREW | |

