

Samsung A71

Problem: Wifi Calling notification always appears on the closed screen

Solution:

Go to Settings

Select Apps

Tap the 3 dots on the upper right hand corner. Select Special access

Look for Wi-Fi control

Scroll down to Wi-Fi Calling move blue slider to the left to turn off this notification.

That's it!